

Configuration guide for Axiom DX8000 Portable Pinpad

Dear customer,

We are pleased that you have chosen one of our terminals. We have already tested your Axiom DX8000 Portable Pinpad extensively and prepared it for operation.


- ① **Please store this document carefully.** The information on your terminal will be needed in the event of service or subsequent initialisation.

{{ReceiptHeader}}	Terminal ID:	{{TerminalId}}
	ep2 Merchant-ID:	{{Ep2MerchantId}}
	Password:	{{TerminalPassword}}


Configuration of your terminal

- ① All selections and confirmations in the following images are made directly on the relevant terminal display.


Step 1




Step 2




Step 3



Step 4



Step 5



Select <Setup>.


Select <Setup network>

Select <Handle network connection>

Select <Wi-Fi Settings> to configure the parameters


Select your network

Step 6




Enter your Wi-Fi
password and
press <Connect>
to finish

Step 7




Go back to the
configuration
menu to start the
configuration

Step 8




Select <MS
Preconfiguration>

Step 9




Choose <ECR
Integrated>

Step 10




Confirm the
productive server

Step 11




Enter the terminal
ID and confirm
with <OK>.

Step 12



The current
software will be
loaded and the
terminal will start
the initialization
process. This may
take a few
minutes.

Step 13



The configuration
and initialization
process is now
completed. Please
confirm both with
<OK>

Step 14



The terminal is
ready for use.